

PIJTTERSEN

E-mail: info@pijttersen.nl / info@catpumps.nl Internet: www.pijttersen.nl / www.catpumps.nl





FEATURES

Poppet reinforced bladder for durability.

02550

Nitrogen precharged to eliminate moisture and bladder deterioration.

Convenient bottom port for easy mounting directly onto discharge manifold.

Sealed valve for positive pressure lock

Reduces pulsation to ±3% to prolong life of pump and system components.

Rechargeable Prrrrr-o-lator **Pulsation Dampeners** Models 07210 02550,020100

SPECIFICATIONS	U.S. Measure	Metric Measure
MODEL 07210		
Maximum Flow	40 GPM*	(160 L/M)
Maximum Working Pressure	3000 PSI**	(210 BAR)
Precharge		(31 BAR)
Bladder Construction		` (NBR)
Maximum Operating Temperature		(82°C)
Volume		(0.70 L)
Safety Factor	4/1	(4/1)
Port Size	1" NPTM	(1" NPTM)
Diameter	4.44"	(113 mm)
Length	7.79"	(198 mm)
Weight	7.28 lbs.	(3.3 kg)
MODEL 02550		
Maximum Flow	10 GPM*	(45 L/M)
Maximum Working Pressure		(500 BAR)
Precharge		(140 BAR)
Bladder Construction		(NBR)
Maximum Operating Temperature		(82°C)
Volume		(0.25 L)
Safety Factor		(4/1)
Port Size		(1/2" NPTF)
Diameter		(115 mm)
Length		(142 mm)
Weight		(2.9 kg)
MODEL 020100		
Maximum Flow	70 GPM*	(265 L/M)
Maximum Working Pressure		(105 BAR)
Precharge		(31 BAR)
Bladder Construction		(NBR)
Maximum Operating Temperature		(82°C)
Volume		(1.97 L)
Safety Factor		(4/1)
Port Size		(1-1/4" NPTM)
Diameter	6.7"	(172 mm)
Length		(217 mm)
Weight		(5.44 kg)
*Authorized system performance. Contact		uous duty performance.

^{**2500} PSI maximum working pressure at 180°F temperature.

NOTE: To order a different prechage than stated, add .800 to model number and specify desired precharge.

Material Codes (Not Part of Part Number): NBR=Medium Nitrile (Buna-N)

^{***6000} PSI maximum working pressure at 180°F temperature.

INSTALLATION INSTRUCTIONS

SELECTION: The Prrrrr-O-Lator should be selected to match the flow and pressure requirements of the system and satisfy the liquid compatibility.

INSTALLATION: The Prrrrr-O-Lator should be mounted directly onto the pump discharge manifold for optimum pulsation dampening and to avoid system vibration damage. Before installing the pulsation dampener, be certain the sealed valve at the top of the accumulator is securely tightened to assure no loss of pressure during operation.

OPERATION: The Prrrrr-O-Lator should be precharged with dry Nitrogen only.

MWARNING

Never use oxygen or air. This could cause an explosion.

Note the standard precharge of the Prrrrr-O-Lator. This may be adjusted to offer a more precise control of pulsation in critical applications such as reverse osmosis. Check this precharge every 12 months for normal operation and more frequently for continuous-duty operation.

At a standard temperature of 70_iF (20_iC), optimum accumulator performance is obtained when the precharge is calibrated at 50% of the system operating pressure.

NOTE


When operating at the lower temperatures, precharge should be 15% higher or 65% of system pressure. When operating at higher temperatures, precharge should be 15% lower or 35% of system pressure.

- NOTF

Up to 50 PSI precharge pressure can be lost during the checking of your precharge.

CAUTION

A gas regulator must be mounted between the nitrogen tank and the hose connection from the Filling and Gauging Assembly to enable you to regulate 50% of the desired system pressure and to prevent excessive pressure being transmitted directly to the accumulator. THIS OVER PRESSURIZATION WILL VOID THE WARRANTY.



FILLING AND GAUGING INSTRUCTIONS

The following are the steps in both checking the precharge of the accumulator and recharging if there should be a loss of pressure or a need for adjustment.

- Before checking your precharge, system pressure should be at zero. TURN SYSTEM OFF.
- SLIGHTLY loosen the sealed valve at the top of the accumulator using a 6mm long handled allen wrench. Thread on the Filling and Gauging Assembly hand tight.
- Be certain the SIDE BLEED VALVE on the gauging assembly is CLOSED.
- Slowly open the LARGE ÒTÓ VALVE at the top of the gauging assembly until completely open. The gauge on the assembly will read the precharge on the accumulator.
- Completely back off (CLOSE) the valve on the gas regulator, open the nitrogen tank valve and read the nitrogen tank pressure on the first gauge.
- 6. If the reading on the gauge assembly is 50% of the system pressure, close the top OTÓ valve and proceed to step 9.
- 7. If the precharge is too high, keep the top ÒTÓ valve open and slowly open the small ÒTÓ valve on the side of the gauging assembly to bleed of pressure.
- 8. If the pressure is less than 50% of the system pressure, slowly open the gas regulator valve until the desired precharge is reached on the second gauge.
- 9. When the gauge reads the required precharge, close the ÒTÓ valve on the top of the gauging assembly to lock the precharge in the accumulator.
- 10. Back off (CLOSE) the gas regulator.
- 11. Proceed with opening the small side ÒTÓ valve on the gauging assembly to relieve (bleed-off) pressure in the assembly and on the second gauge on the gas regulator.
- 12. Close the side ÒTÓ valve on the gauging assembly and remove the assembly from the accumulator.
- 13. Tighten the accumulator sealed valve and resume operation.

30731 Complete Filling and Gauging Assembly (Optional)





PIJTTERSEN

Pijttersen B.V. Stavangerweg 14A 9723 JC GRONINGEN THE NETHERLANDS

Tel.: +31 (0)50-8200963

E-mail: info@pijttersen.nl/info@catpumps.nl Internet: www.pijttersen.nl/www.catpumps.nl

