

5DX, 6DX, 66DX PLUNGER PUMP SERVICE MANUAL



5DX MODELS: 5DX30G1, 5DX35G1, 5DX40G1, 5DX50G1
6DX MODELS: 6DX35G1I, 6DX40G1I
66DX MODELS: 66DX30G1I, 66DX35G1I, 66DX40G1I

INSTALLATION AND START-UP INFORMATION

Optimum performance of the pump is dependent upon the entire liquid system and will be obtained only with the proper selection, installation of plumbing, and operation of the pump and accessories.

SPECIFICATIONS: Maximum specifications refer to individual attributes. It is **not** implied that **all maximums** can be performed **simultaneously**. If more than one maximum is considered, check with your CAT PUMPS supplier to confirm the proper performance and pump selection. Refer to individual Data Sheets for complete specifications, parts list and exploded view.

LUBRICATION: Fill crankcase with special CAT PUMP Hydraulic oil per pump specifications [5DX-22.65 oz., 6DX-18.6 oz., 66DX-18.0 oz.]. DO NOT RUN PUMP WITHOUT OIL IN CRANKCASE. Change initial fill after 50 hours running period. Thereafter, change oil every **3 months or 500 hour intervals**.

DRIVE SELECTION: The pump shaft size is a 1" gas shaft. The engine driving the pump must be of adequate horsepower to maintain full RPM when the pump is under load. Select the horsepower requirement according to required pump discharge flow and maximum **pressure at the pump!** Consult the manufacturer of gas or diesel engine for selection of the proper engine.

MOUNTING: All DX models are direct-drive and come with a flange adapter that mounts to a gas engine. Before mounting pump to gas engine, apply PN 6106 antiseize lubricant to pump shaft. Refer to Technical Bulletin 055 for instructions on removing pump from gas engine. To minimize piping stress, **use appropriate flexible hose to inlet and discharge ports**.

LOCATION: If the pump is used in extremely dirty or humid conditions, it is recommended pump be enclosed. Do not store or operate in excessively high temperature areas or without proper ventilation. Liquid temperatures above 130°F are permissible. Add 1/2 PSI inlet pressure per each degree F over 130°F. Elastomer or RPM changes may be required. See Tech Bulletin 002 or call CAT PUMPS for recommendations.

INLET CONDITIONS: Refer to complete **Inlet Condition Check-List** in this manual before starting system. DO NOT STARVE THE PUMP OR RUN DRY.

DISCHARGE CONDITIONS: OPEN ALL VALVES BEFORE STARTING SYSTEM to avoid deadhead overpressure condition and severe damage to the pump or system.

A **reliable Pressure Gauge** should be installed near the discharge outlet of the high pressure manifold. This is extremely important for adjusting pressure regulating devices and also for proper sizing of the nozzle or restricting orifice. The pump is rated for a maximum pressure; this is the **pressure** which would be **read at the discharge manifold of the pump, NOT AT THE GUN OR NOZZLE**.

Use PTFE thread tape or pipe thread sealant (sparingly) to connect accessories or plumbing. Exercise caution not to wrap tape beyond the last thread to avoid tape from becoming lodged in the pump or accessories. This condition will cause a malfunction of the pump or system.

PRESSURE REGULATION: All systems require both a primary pressure regulating device (i.e., regulator, unloader) and a secondary pressure safety relief device (i.e., pop-off valve, safety valve). The primary pressure device must be installed on the discharge side of the pump. The function of the primary pressure regulating device is to protect the pump from over pressurization, which can be caused by a plugged or closed off discharge line. Over pressurization can severely damage the pump, other system components and can cause bodily harm. The secondary safety relief device must be installed **in-line** between the primary device and pump **or on the opposite side of the manifold head**. This will ensure pressure relief of the system if the primary regulating device fails. Failure to install such a safety device will void the warranty on the pump.

NOZZLES: A worn nozzle will result in loss of pressure. Do not adjust pressure regulating device to compensate. Replace nozzle and reset regulating device to system pressure.

PUMPED LIQUIDS: Some liquids may require a **flush between operations or before storing**. For pumping liquids other than water, contact your CAT PUMPS supplier.

STORING: For extended storing or between use in cold climates, drain all pumped liquids from pump and **flush with antifreeze solution to prevent freezing and damage** to the pump. DO NOT RUN PUMP WITH FROZEN LIQUID (refer to Tech Bulletin 083).

WARNING

All systems require both a primary pressure regulating device (i.e., regulator, unloader) and a secondary pressure safety relief device (i.e., pop-off valve, safety valve). Failure to install such relief devices could result in personal injury or damage to the pump or to system components. CAT PUMPS does not assume any liability or responsibility for the operation of a customer's high pressure system.




PIJTTERSEN

Pijtersen B.V.
Stavangerweg 14A
9723 JC GRONINGEN
THE NETHERLANDS

Tel.: +31 (0)50-8200963
E-mail : info@pijtersen.nl / info@catpumps.nl
Internet: www.pijtersen.nl / www.catpumps.nl




The Pumps with Nine Lives



Removal of Valve Assemblies



Valve Assembly Components



Separation of Manifold Head from Crankcase

CAUTION: Before commencing with service, shut off drive (electric motor, gas or diesel engine) and turn off water supply to pump. Relieve all discharge line pressure by triggering gun or opening valve in discharge line. Inspect and service all system accessories on the same schedule as your pump.

After servicing is completed, turn on water supply to pump, start drive, reset pressure regulating device and secondary valve, read system pressure on the gauge at the pump head. Check for any leaks, vibration or pressure fluctuations and resume operation

SERVICING THE VALVES

Disassembly


1. Using an M24 hex tool, remove the top discharge and bottom inlet Valve Plugs.
2. Using a pliers, grasp the Spring Retainer by the tab at the top and remove from the valve chamber.
3. If the Valve assembly separates during removal, remove the Spring and Valve with a needle nose pliers. Then with a reverse pliers, remove the Valve Seat from the valve chamber.
4. To separate the Valve assembly, insert a screwdriver into the side of the Retainer and press on the back side of the Valve until Seat separates from the Spring Retainer.
5. Remove O-Ring from each Seat and Valve Plug.

Reassembly

1. Examine Spring Retainers for internal wear or breaks in the structure and replace as needed.
2. Examine Springs for fatigue or breaks and replace as needed.
3. Examine Valves and Seats for grooves, pitting or wear and replace as needed.
4. Examine Seat and Valve Plug O-Rings for cuts or wear and replace as needed.

NOTE: Inlet and Discharge Valve Assemblies are interchangeable. Two Valve Kits are needed for a complete valve change.

5. Lubricate and install new O-Ring onto outside diameter of Seat.
6. Place Seat on work surface **with small diameter side up**.
7. Place Valve onto Seat **with concave side down**.
8. Place Spring on Valve.
9. Install Spring Retainer with deep stepped end **over** Spring and snap onto Seat.
10. Press complete Valve assembly into each valve chamber until completely seated.
11. Lubricate and install new O-Ring onto each Valve Plug.
12. Apply Loctite® 242® to threads of each Valve Plug and thread in hand tight. Torque to specifications per chart.



Removal of Seal Case and Lo-Pressure Seal



V-Packing and Lo-Pressure Seal Components



Reassembly of V-Packings

SERVICING THE SEALS

Disassembly

1. Using an M6 allen wrench, remove the eight Hex Socket Head (HSH) screws from the face of the Manifold Head.
2. Insert flat head screwdrivers on each side between the Crankcase and Manifold Head. Gently apply pressure to the head to begin separation.
3. Support the Manifold Head from the underside and pull the Manifold Head away from the crankcase.

CAUTION: Keep the Manifold Head properly aligned with the Ceramic Plungers when removing to avoid damage to the plungers.

NOTE: The Seal Case may stay in the manifold or on the plungers.

4. Place Manifold Head on work surface **with crankcase side up**.
5. Remove Seal Retainer from each Plunger Rod.
6. Use a screwdriver to pry out the Lo-Pressure Seal from each Seal Case.

CAUTION: Screwdriver will damage seal during removal.

7. Use reverse pliers to remove Seal Case from each seal chamber.

NOTE: Insert the reverse pliers into the second lip to avoid damage to the Seal Case.

8. Carefully insert a small screwdriver under the O-Ring and roll the O-Ring off each Seal Case.

CAUTION: Exercise caution as the screwdriver may score O-Ring sealing surface.


9. Remove V-Packing and Male Adapter from each seal chamber by hand or with a reverse pliers.

Reassembly


1. Examine the manifold chamber walls for scale buildup or damage.
2. Examine V-Packings for frayed edges or uneven wear and replace as needed.
3. Examine Seal Case O-Rings for cuts or deterioration and replace as needed.
4. Examine Lo-Pressure Seals for wear to the internal ridges and outer surfaces or for broken springs and replace as needed.

NOTE: Seals and O-Rings are available in Seal Kits.

5. Examine Seal Retainers for deformation and replace as needed.
6. Lubricate and install Male Adapter **with notch side down**. Lubricate and install new V-Packing by hand into seal chamber **with grooved side down**.
7. Lubricate and install O-Ring on each Seal Case. Press small end of Seal Case into each seal chamber.
8. Lubricate and press new Lo-Pressure Seal into each Seal Case **with the garter spring down**.
9. Examine Ceramic Plungers for scoring, scale buildup, chips or cracks and replace as needed.
10. Slide Seal Retainer over each Ceramic Plunger **with the openings to the top and bottom**. Press into the Crankcase.
11. Rotate crankshaft by hand so the two outside plungers are extended equally.
12. Lightly lubricate Ceramic Plungers, then carefully slide the Manifold Head over the Ceramic Plungers, supporting it from the underside to avoid damage to the plungers or seals. Press the Manifold Head flush with the Crankcase.
13. Thread HSH screws in hand tight. Torque in sequence to specifications in torque chart.



Removal of Plunger Retainer



Ceramic Plunger and Retainer Components

SERVICING THE PLUNGERS

Disassembly

NOTE: Refer to Tech Bulletin 071 (old 4HP Plunger Rod Change) for additional information on Ceramic Plungers.

1. Disconnect all plumbing from the manifold head.
2. Remove unloader by using a M22 wrench to remove the top unloader Flow-Thru screw and a M27 wrench to remove the bottom unloader Flow-Thru screw.
3. Using an M6 Allen Tool remove the eight HSH screws from the face of the Manifold head.
4. Insert flat head screwdrivers on each side between the Crankcase and Manifold Head and gently apply pressure to the head to begin separation.
5. Support the Manifold Head from the underside and pull the Manifold Head away from the crankcase.


CAUTION: Keep the Manifold Head properly aligned with the Ceramic Plungers when removing to avoid damage to the plungers or seals.

6. Remove Seal Retainer from each Plunger Rod.
7. Using a M10 hex tool, loosen the Plunger Retainer on each Plunger Rod approximately three to four turns.
8. Push the Ceramic Plunger back towards the Crankcase to separate from the Plunger Retainer and proceed with unthreading the Plunger Retainer by hand.
9. Remove the Barrier Slinger, Ceramic Plunger and Seal Washer from each Plunger Retainer.

Reassembly

1. Visually inspect the Crankcase Oil Seals for deterioration or leaks. Contact CAT PUMPS for assistance with replacement. See **SERVICING THE CRANKCASE SECTION**.
 2. Examine Seal Washers and Barrier Slingers for cuts for wear and replace as needed.
 3. Examine Plunger Retainers for damaged threads and replace as needed.
 4. Examine the Ceramic Plungers for scoring, scale buildup, chips or cracks and replace as needed. The Ceramic Plungers typically do not need to be replaced with every seal servicing.
 5. Install new Seal Washer onto each Plunger Retainer.
 6. Slide Plunger Retainer with Seal Washer into flat end of Ceramic Plunger. Install Barrier Slinger on Plunger Retainer.
- NOTE: Ceramic Plungers can only be installed in one direction. Slotted end of Ceramic Plunger should face toward crankcase.**
7. Apply Loctite® 242® to exposed threaded end of Plunger Retainer.
 8. Install Ceramic Plunger with Plunger Retainer, Seal Washer and Barrier Slinger over each Plunger Rod shoulder and thread hand tight. Torque to specifications per chart.
 9. Slide Seal Retainer over each Ceramic Plunger with the openings to the top and bottom. Press into Crankcase.
 10. Rotate crankshaft by hand so the two outside plungers are extended equally.
 11. Lightly lubricate Ceramic Plungers, then carefully slide the Manifold Head over the Ceramic Plungers, supporting it from the underside to avoid damage to the plungers or seals. Press the Manifold Head flush with the Crankcase.
 12. Thread HSH screws in hand tight. Torque in sequence to specifications in torque chart.

TORQUE SEQUENCE



SERVICING THE CRANKCASE SECTION

1. While Manifold, Plungers and Seal Retainers are removed, examine Crankcase Oil Seals for leaking and wear.
2. Check for any signs of leaking at Bearing Covers, Rear Cover, Drain Plug or Bubble Gauge.
3. Check oil level and for evidence of water in oil. Change crankcase oil on a regular schedule. See Preventative Maintenance Check-List.
4. Rotate Crankshaft by hand to feel for smooth bearing movement.
5. Examine Crankshaft Oil Seals externally for drying, cracking or leaking.
6. Contact CAT PUMPS or your local distributor if crankcase service is evidenced.

SERVICING THE UNLOADER/CHEMICAL INJECTOR

Disassembly

1. Remove black Adjusting Handle.
2. Remove brass Adjusting Cap by turning in a **counter-clockwise direction**.
3. Remove exposed Coil Spring and flat Spring Retainer.
4. Using a wrench, remove Piston Retainer by turning in a **counterclockwise direction**.

NOTE: The Piston Stem and Valve Assembly may fall out when the piston retainer is removed. If so, proceed to step 7., If not, continue with step 5.

5. Use a needle nose pliers to remove Piston Stem and Valve Assembly.
6. Separate Piston Stem from Valve/Ball Assembly by securing the Valve/Ball Assembly near the Spacer. Insert a screwdriver into slotted head of Piston Stem and unthread from Valve/Ball Assembly.

CAUTION: Exercise extreme caution to avoid contact and damage to the tapered surface of Valve/Ball Assembly.

7. Examine Seat at the bottom of the unloader chamber for grooves, pitting or wear, replace only as needed.

CAUTION: Seat will be damaged when removed.

8. On the 5DX model, remove Discharge Fitting with O-Ring. On the 6DX and 66DX models remove Chemical Injector with O-Ring.
9. Remove Spring and Check Valve with O-Ring.

Reassembly

NOTE: All O-Rings are available in an O-Ring Kit. Other components sold separately.

1. If seat is worn or damaged, press new seat into unloader chamber until squarely seated.
2. Examine Piston Stem, Washer, Spacer and Valve/Ball Assembly for grooves, pitting or wear and replace as needed. Examine O-Rings and Back-up Ring for cuts or wear and replace as needed.
3. Lubricate and install O-Ring over slotted head of Piston Stem, then position Back-up Ring on top of O-Ring.
4. Lubricate and install O-Rings on Spacer.
5. Install Washer and then Spacer with O-Rings onto Piston Stem. Apply Loctite® 242® to threads of Piston Stem and screw Valve/Ball Assembly onto Piston Stem.
6. Lower complete Piston Stem and Valve Assembly into unloader chamber with Valve/Ball Assembly facing downward.
7. Examine Piston Retainer for damaged threads or wear and replace as needed. Examine O-Ring for cuts or wear and replace as needed.
8. Apply Loctite® 242® to Piston Retainer threads and then hand thread Piston Retainer into unloader by turning in a clockwise direction, and then tighten with wrench.
9. Examine Spring Retainer and Coil Spring for fatigue or breaks and replace as needed.
10. Place Spring Retainer into Piston Retainer, followed by Coil Spring.
11. Thread brass Adjusting Cap onto Piston Retainer by turning in a **clockwise direction**.
12. On the 66DX models, slide black Adjusting Handle over brass Adjusting Cap.
13. On the 6DX and 66DX models, examine Chemical Injector Check Valve and Spring for fatigue or wear and replace as needed. Examine O-Ring for cuts or wear and replace as needed.
14. Install Spring into inlet port of Chemical Injector.
15. Lubricate and install Check Valve with O-Ring into inlet port of Chemical Injector with O-Ring facing out.
16. Apply Loctite® 242® to threads of Chemical Injector and hand thread into unloader by turning in a clockwise direction and then tighten with wrench.

PREVENTATIVE MAINTENANCE CHECK-LIST

| Check | Daily | Weekly | 50 hrs. | 500 hrs.* | 1500 hrs.** | 3000 hrs.** |
|--------------------|-------|--------|---------|-----------|-------------|-------------|
| Clean Filters | x | | | | | |
| Oil Level/Quality | x | | | | | |
| Oil Leaks | x | | | | | |
| Water Leaks | x | | | | | |
| Belts, Pulley | | x | | | | |
| Plumbing | | x | | | | |
| Initial Oil Change | | | x | | | |
| Oil Change | | | | x | | |
| Seal Change | | | | | x | |
| Valve Change | | | | | | x |
| Accessories | | | | | x | |

* If other than CAT PUMPS special multi-viscosity ISO68 oil is used, change cycle should be every 300 hours.

** Each system's maintenance cycle will be exclusive. If system performance decreases, check immediately. If no wear at 1500 hours, check again at 2000 hours and each 500 hours until wear is observed. Valves typically require changing every other seal change.

Duty cycle, temperature, quality of pumped liquid and inlet feed conditions all effect the life of pump wear parts and service cycle.

** Remember to service the regulator/unloader at each seal servicing and check all system accessories and connections before resuming operation.

TORQUE CHART

| Pump Model | Thread | Tool Size [P/N] | Torque | | |
|-----------------------------|----------|------------------------|----------|----------|-----|
| | | | in. lbs. | ft. lbs. | Nm |
| Plunger Retainer | M6 | M10 Hex [25082] | 55 | 4.6 | 6.2 |
| Flow-Thru Screws | | | | | |
| Inlet | 1/2" NPT | M27 Hex | 360 | 30 | 40 |
| Discharge | 3/8" NPT | M22 Hex | 384 | 32 | 44 |
| Manifold Head Screws | M8 | M6 Allen [30941] | 132 | 11.0 | 15 |
| Valve Plugs | M22 | M24 Hex [44046] | 870 | 72.5 | 98 |
| Rear Cover Screws | M6 | M10 Hex [25082] | 50 | 4.0 | 5.4 |
| Bearing Cover Screws | | | | | |
| 5DX, 6DX | M8 | M13 Hex [25324] | 115 | 9.58 | 13 |
| 66DX | M6 | M10 Hex [25082] | 50 | 4.0 | 5.4 |
| Bubble Oil Gauge | M28 | Oil Gauge Tool [44050] | 45 | 3.6 | 5 |

TECHNICAL BULLETIN REFERENCE CHART

| No. | Subject | Models |
|-----|---|--|
| 002 | Inlet Pressure VS Liquid Temperature | All Models |
| 024 | Lubrication of Lo-Pressure Seals | All Models |
| 036 | Cylinder and Plunger Reference Chart | All Models |
| 043 | Plunger Pump LPS and HPS Servicing | All Plunger Models |
| 055 | Removing Pumps from Gas or Electric Motor | 2SF, 2SFX, 2X, 2DX, 3DX, 3SP, 4SF, 4HP, 5DX, 6DX, 66DX |
| 060 | Baffle Assembly | 34170 |
| 071 | Plunger Rod Change - HP Pumps | 4HP, 5DX |
| 074 | Torque Chart | All Models |
| 083 | Winterizing a Pump | All Models |

INLET CONDITION CHECK-LIST

Review Before Start-Up

Inadequate inlet conditions can cause serious malfunctions in the best designed pump. Surprisingly, the simplest of things can cause the most severe problems or go unnoticed to the unfamiliar or untrained eye. **REVIEW THIS CHECK-LIST BEFORE OPERATION OF ANY SYSTEM.** Remember, no two systems are alike, so there can be no **ONE** best way to set-up a system. All factors must be carefully considered.

INLET SUPPLY should exceed the maximum flow being delivered by the pump to assure proper performance.

- ☐ Open inlet shut-off valve and turn on water supply to avoid starving the pump. **DO NOT RUN PUMP DRY.**
- ☐ Temperatures above 130°F are permissible. Add 1/2 PSI inlet pressure per each degree F over 130°F. Elastomer or RPM changes may be required. See Tech Bulletin 002 or call CAT PUMPS for recommendations.
- ☐ Avoid closed loop systems especially with high temperature, ultra-high pressure or large volumes. Conditions vary with regulating/unloader valve.
- ☐ Higher temperature liquids tend to vaporize and require positive heads.
- ☐ When using an inlet supply reservoir, size it to provide adequate liquid to accommodate the maximum output of the pump, generally a minimum of 6-10 times the GPM (however, a combination of system factors can change this requirement); provide adequate baffling in the tank to eliminate air bubbles and turbulence; install diffusers on all return lines to the tank.

INLET LINE SIZE should be adequate to avoid starving the pump.

- ☐ Line size must be a minimum of one size larger than the pump inlet fitting. Avoid tees, 90 degree elbows or valves in the inlet line of the pump to reduce the risk of flow restriction and cavitation.
- ☐ The line **MUST** be a FLEXIBLE hose, NOT a rigid pipe, and reinforced on SUCTION systems to avoid collapsing.
- ☐ The simpler the inlet plumbing the less the potential for problems. Keep the length to a minimum, the number of elbows and joints to a minimum (ideally no elbows) and the inlet accessories to a minimum.
- ☐ Use pipe sealant to assure air-tight, positive sealing pipe joints.

INLET PRESSURE should fall within the specifications of the pump.

- ☐ Acceleration loss of liquids may be increased by high RPM, high temperatures, low vapor pressures or high viscosity and may require a pressurized inlet to maintain adequate inlet supply.
- ☐ Optimum pump performance is obtained with +20 PSI (1.4 BAR) inlet pressure. With adequate inlet plumbing, most pumps will perform with flooded suction. Maximum inlet pressure is 75 PSI (5.25 BAR).
- ☐ After prolonged storage, pump should be rotated by hand and purged of air to facilitate priming. Disconnect the discharge port and allow liquid to pass through pump and measure flow.

INLET ACCESSORIES are designed to protect against over pressurization, control inlet flow, contamination or temperature and provide ease of servicing.

- ☐ A shut-off valve is recommended to facilitate maintenance.
- ☐ A stand pipe can be used in some applications to help maintain a positive head at the pump inlet line.
- ☐ Inspect and clean inlet filters on a regular schedule to avoid flow restriction.
- ☐ A pressure transducer is necessary to accurately read inlet pressure. **Short term, intermittent cavitation will not register on a standard gauge.**
- ☐ All accessories should be sized to avoid restricting the inlet flow.
- ☐ All accessories should be compatible with the solution being pumped to prevent premature failure or malfunction.

BY-PASS TO INLET

- ☐ The standard 5DX, 6DX and 66DX pump comes with a Regulating Unloader. This Regulating Unloader has a **built-in by-pass channel** which routes liquid back to the inlet during the by-pass mode. No additional plumbing is required.
- ☐ It is critical that a Thermo Valve be installed to protect the pump during prolonged by-pass. The Thermo Valve may be installed on the opposite side of the Manifold Head or by replacing the Flow-Thru Screw with the Flow-Thru Direct Mount Thermo Valve (PN 33920).

HOSE FRICTION LOSS

| Water* Flow Gal/Min | PRESSURE DROP IN PSI PER 100 FT OF HOSE WITH TYPICAL WATER FLOW RATES Hose Inside Diameters, Inches | | | | | | |
|---------------------------|---|------|------|-----|-----|-----|----|
| | 1/4 | 5/16 | 3/8 | 1/2 | 5/8 | 3/4 | 1" |
| 0.5 | 16 | 5 | 2 | | | | |
| 1 | 54 | 20 | 7 | 2 | | | |
| 2 | 180 | 60 | 25 | 6 | 2 | | |
| 3 | 380 | 120 | 50 | 13 | 4 | 2 | |
| 4 | | 220 | 90 | 24 | 7 | 3 | |
| 5 | | 320 | 130 | 34 | 10 | 4 | |
| 6 | | | 220 | 52 | 16 | 7 | 1 |
| 8 | | | 300 | 80 | 25 | 10 | 2 |
| 10 | | | 450 | 120 | 38 | 14 | 3 |
| 15 | | | 900 | 250 | 80 | 30 | 7 |
| 20 | | | 1600 | 400 | 121 | 50 | 12 |
| 25 | | | | 650 | 200 | 76 | 19 |
| 30 | | | | | 250 | 96 | 24 |
| 40 | | | | | 410 | 162 | 42 |
| 50 | | | | | 600 | 235 | 62 |
| 60 | | | | | | 370 | 93 |

*At a fixed flow rate with a given size hose, the pressure drop across a given hose length will be directly proportional. A 50 ft. hose will exhibit one-half the pressure drop of a 100 ft. hose. Above values shown are valid at all pressure levels.

WATER LINE PRESSURE LOSS PRESSURE DROP IN PSI PER 100 FEET

| Water GPM | Steel Pipe—Nominal Dia. | | | | | | Brass Pipe—Nominal Dia. | | | | | | Copper Tubing O.D. Type L | | | | | | | |
|--------------|-------------------------|-----|-----|-----|-----|-------|-------------------------|-----|-----|-----|-----|-----|---------------------------|-------|-----|-----|-----|-----|-----|-----|
| | 1/4 | 3/8 | 1/2 | 3/4 | 1 | 1 1/4 | 1 1/2 | 1/4 | 3/8 | 1/2 | 3/4 | 1 | 1 1/4 | 1 1/2 | 1/4 | 3/8 | 1/2 | 5/8 | 3/4 | 7/8 |
| 1 | 8.5 | 1.9 | | | | | | 6.0 | 1.6 | | | | | | 120 | 13 | 2.9 | 1.0 | | |
| 2 | 30 | 7.0 | 2.1 | | | | | 20 | 5.6 | 1.8 | | | | | 400 | 45 | 10 | 3.4 | 1.3 | |
| 3 | 60 | 14 | 4.5 | 1.1 | | | | 40 | 11 | 3.6 | | | | | 94 | 20 | 6.7 | 2.6 | | |
| 5 | 150 | 36 | 12 | 2.8 | | | | 100 | 28 | 9.0 | 2.2 | | | | 230 | 50 | 17 | 6.1 | 3.0 | |
| 8 | 330 | 86 | 28 | 6.7 | 1.9 | | | 220 | 62 | 21 | 5.2 | 1.6 | | | 500 | 120 | 40 | 15 | 6.5 | |
| 10 | 520 | 130 | 43 | 10 | 3.0 | | | 320 | 90 | 30 | 7.8 | 2.4 | | | 180 | 56 | 22 | 10 | | |
| 15 | 270 | 90 | 21 | 6.2 | 1.6 | | | 190 | 62 | 16 | 5.0 | 1.5 | | | 120 | 44 | 20 | | | |
| 25 | 670 | 240 | 56 | 16 | 4.2 | 2.0 | | 470 | 150 | 40 | 12 | 3.8 | 1.7 | | 330 | 110 | 50 | | | |
| 40 | | | | | 66 | 17 | 8.0 | | | | | 39 | 11 | 5.0 | | | | 550 | 200 | 88 |
| 60 | | | | | | 37 | 17 | | | | | | 23 | 11 | | | | | | |
| 80 | | | | | | | 52 | 29 | | | | | 40 | 19 | | | | | | |
| 100 | | | | | | | 210 | 107 | 48 | | | | | 61 | 28 | | | | | |


RESISTANCE OF VALVES AND FITTINGS

| Nominal Pipe Size Inches | Inside Diameter Inches | Equivalent Length of Standard Pipe in Feet | | | | | | | |
|-----------------------------------|------------------------------|--|----------------|----------------|--------------|--------------|----------------------|--------------------|-----------------------|
| | | Gate Valve | Globe Valve | Angle Valve | 45° Elbow | 90° Elbow | 180° Close Ret | Tee Thru Run | Tee Thru Branch |
| 1/2 | 0.622 | 0.41 | 18.5 | 9.3 | 0.78 | 1.67 | 3.71 | 0.93 | 3.33 |
| 3/4 | 0.824 | 0.54 | 24.5 | 12.3 | 1.03 | 2.21 | 4.90 | 1.23 | 4.41 |
| 1 | 1.049 | 0.69 | 31.2 | 15.6 | 1.31 | 2.81 | 6.25 | 1.56 | 5.62 |
| 1 1/4 | 1.380 | 0.90 | 41.0 | 20.5 | 1.73 | 3.70 | 8.22 | 2.06 | 7.40 |
| 1 1/2 | 1.610 | 1.05 | 48.0 | 24.0 | 2.15 | 4.31 | 9.59 | 2.40 | 8.63 |
| 2 | 2.067 | 1.35 | 61.5 | 30.8 | 2.59 | 5.55 | 12.30 | 3.08 | 11.60 |
| 2 1/2 | 2.469 | 1.62 | 73.5 | 36.8 | 3.09 | 6.61 | 14.70 | 3.68 | 13.20 |
| 3 | 3.068 | 2.01 | 91.5 | 45.8 | 3.84 | 8.23 | 18.20 | 4.57 | 16.40 |
| 4 | 4.026 | 2.64 | 120.0 | 60.0 | 5.03 | 10.80 | 23.90 | 6.00 | 21.60 |

Arriving at a total line pressure loss, consideration should then be given to pressure loss created by valves, fittings and elevation of lines.

If a sufficient number of valves and fittings are incorporated in the system to materially affect the total line loss, add to the total line length, the equivalent length of line of each valve or fitting.

TYPICAL RESERVOIR TANK RECOMMENDED 6 TO 10 TIMES SYSTEM CAPACITY



Handy Formulas to Help You

Q. How can I find the RPM needed to get specific GPM (Gallons Per Minute) I want?

$$A. \text{Desired RPM} = \text{Desired GPM} \times \frac{\text{Rated RPM}}{\text{Rated GPM}}$$

Q. I have to run my pump at a certain RPM. How do I figure the GPM I'll get?

$$A. \text{Desired GPM} = \text{Desired RPM} \times \frac{\text{Rated GPM}}{\text{Rated RPM}}$$

Q. Is there a simple way to find the approximate horsepower I'll need to run the pump?

$$A. \text{Electric Brake Horsepower Required} = \frac{\text{GPM} \times \text{PSI}}{1460} \quad (\text{Standard 85\% Mech. Efficiency})$$



Q. What size motor pulley should I use?

$$A. \text{Pump Pulley (Outer Diameter)} \times \frac{\text{Pump RPM}}{\text{Motor/Engine RPM}} \quad (\text{Consult Engine Mfr.})$$

Q. How do I calculate the torque for my hydraulic drive system?

$$A. \text{Torque (ft. lbs.)} = 3.6 \left(\frac{\text{GPM} \times \text{PSI}}{\text{RPM}} \right)$$

Avoid Cavitation Damage



One or several of the conditions shown in the chart below may contribute to cavitation in a system resulting in premature wear, system downtime and unnecessary operating costs.

| CONDITION | SOLUTION |
|--|--|
| Inadequate inlet line size | • Increase line size to the inlet port or one size larger |
| Water hammering liquid acceleration/deacceleration | • Install C.A.T. Tube • Move pump closer to liquid supply |
| Rigid Inlet Plumbing | • Use flexible wire reinforced hose to absorb pulsation and pressure spikes |
| Excessive Elbows in Inlet Plumbing | • Keep elbows to a minimum and less than 90° |
| Excessive liquid Temperature | • Use Thermo Valve in bypass line • Do not exceed pump temperature specifications • Substitute closed loop with baffled holding tank • Adequately size tank for frequent or high volume bypass • Pressure feed high temperature liquids • Properly ventilate cabinets and rooms |
| Air Leaks in Plumbing | • Check all connections • Use PTFE thread tape or pipe thread sealant |
| Agitation in Supply Tank | • Size tank according to pump output — Minimum 6-10 times system GPM • Baffle tank to purge air from liquid and separate inlet from discharge |
| High Viscosity Liquids | • Verify viscosity against pump specifications before operation • Elevate liquid temperature enough to reduce viscosity • Lower RPM of pump • Pressure feed pump • Increase inlet line size |
| Clogged Filters | • Perform regular maintenance or use clean filters to monitor build up • Use adequate mesh size for liquid and pump specifications |

DIAGNOSIS AND MAINTENANCE

One of the most important steps in a high pressure system is to establish a regular maintenance program. This will vary slightly with each system and is determined by various elements such as the duty cycle, the liquid being pumped, the actual specifications vs rated specifications of the pump, the ambient conditions, the inlet conditions and the accessories in the system. A careful review of the necessary inlet conditions and protection devices required before the system is installed will eliminate many potential problems.

CAT PUMPS are very easy pumps to service and require far less frequent service than most pumps. Typically, only common tools are required, making in-field service convenient, however, there are a few custom tools, special to certain models, that do simplify the process. This service manual is designed to assist you with the disassembly and reassembly of your pump. The following guide will assist in determining the cause and remedy to various operating conditions. You can also review our **FAQ** or **SERVICE** sections on our **WEB SITE** for more facts or contact CAT PUMPS directly.

| PROBLEM | PROBABLE CAUSE | SOLUTION |
|------------------------------------|---|--|
| Low pressure | <ul style="list-style-type: none">•Worn nozzle.•Air leak in inlet plumbing.•Pressure gauge inoperative or not registering accurately.•Relief valve stuck, partially plugged or improperly adjusted.•Inlet suction strainer (filter) clogged or improperly sized.•Abrasives in pumped liquid.•Leaky discharge hose.•Inadequate liquid supply.•Severe cavitation.•Worn seals.•Worn or dirty inlet/discharge valves. | <ul style="list-style-type: none">•Replace with properly sized nozzle.•Tighten fittings and hoses. Use PTFE liquid or tape.•Check with new gauge. Replace worn or damaged gauge.•Clean/adjust relief valve. Replace worn seats/valves and o-rings.•Clean filter. Use adequate size filter. Check more frequently.•Install proper filter.•Replace discharge hose with proper rating for system.•Pressurize inlet and install C.A.T.•Check inlet conditions.•Install new seal kit. Increase frequency of service.•Clean inlet/discharge valves or install new valve kit. |
| Pulsation | <ul style="list-style-type: none">•Faulty Pulsation Dampener.•Foreign material trapped in inlet/discharge valves. | <ul style="list-style-type: none">•Check precharge. If low, recharge, or install a new dampener.•Clean inlet/discharge valves or install new valve kit. |
| Water leak | | |
| •Under the manifold | <ul style="list-style-type: none">•Worn V-Packings or Lo-Pressure Seals.•Worn adapter o-rings. | <ul style="list-style-type: none">•Install new seal kit. Increase frequency of service.•Install new o-rings. |
| •Into the crankcase | <ul style="list-style-type: none">•Humid air condensing into water inside the crankcase.•Excessive wear to seals and V-Packings. | <ul style="list-style-type: none">•Install oil cap protector. Change oil every 3 months or 500 hours.•Install new seal kit. Increase frequency of service. |
| Knocking noise | | |
| •Inlet supply | <ul style="list-style-type: none">•Inadequate inlet liquid supply. | <ul style="list-style-type: none">•Check liquid supply. Increase line size, pressurize or install C.A.T. |
| •Bearing | <ul style="list-style-type: none">•Broken or worn bearing. | <ul style="list-style-type: none">•Replace bearing. |
| Oil leak | | |
| •Crankcase oil seals. | <ul style="list-style-type: none">•Worn crankcase oil seals. | <ul style="list-style-type: none">•Replace crankcase oil seals. |
| •Crankshaft oil seals and o-rings. | <ul style="list-style-type: none">•Worn crankshaft oil seals or o-rings on bearing cover. | <ul style="list-style-type: none">•Remove bearing cover and replace o-rings and/or oil seals. |
| •Drain plug | <ul style="list-style-type: none">•Loose drain plug or worn drain plug o-ring. | <ul style="list-style-type: none">•Tighten drain plug or replace o-ring. |
| •Bubble gauge | <ul style="list-style-type: none">•Loose bubble gauge or worn bubble gauge gasket. | <ul style="list-style-type: none">•Tighten bubble gauge or replace gasket. |
| •Rear cover | <ul style="list-style-type: none">•Loose rear cover or worn rear cover o-ring. | <ul style="list-style-type: none">•Tighten rear cover or replace o-ring. |
| •Filler cap | <ul style="list-style-type: none">•Loose filler cap or excessive oil in crankcase. | <ul style="list-style-type: none">•Tighten filler cap. Fill crankcase to specified capacity. |
| Pump runs extremely rough | | |
| •Inlet conditions | <ul style="list-style-type: none">•Restricted inlet or air entering the inlet plumbing | <ul style="list-style-type: none">•Correct inlet size plumbing. Check for air tight seal. |
| •Pump valves | <ul style="list-style-type: none">•Stuck inlet/discharge valves. | <ul style="list-style-type: none">•Clean out foreign material or install new valve kit. |
| •Pump seals | <ul style="list-style-type: none">•Leaking V-Packings or Lo-Pressure seals. | <ul style="list-style-type: none">•Install new seal kit. Increase frequency of service. |
| Premature seal failure | <ul style="list-style-type: none">•Scored plungers.•Over pressure to inlet manifold.•Abrasive material in the liquid being pumped.•Excessive pressure and/or temperature of pumped liquid.•Running pump dry.•Starving pump of adequate liquid. •Eroded manifold. | <ul style="list-style-type: none">•Replace plungers.•Reduce inlet pressure per specifications.•Install proper filtration at pump inlet and clean regularly.•Check pressure and inlet liquid temperature.•DO NOT RUN PUMP WITHOUT LIQUID.•Increase hose one size larger than inlet port size. Pressurize and install C.A.T.•Replace manifold. Check liquid compatibility. |