

25PFR PLUNGER PUMP SERVICE MANUAL



25 FRAME SPLIT MANIFOLD : 2530, 2531, 2537

INSTALLATION AND START-UP INFORMATION

Optimum performance of the pump is dependent upon the entire liquid system and will be obtained only with the proper selection, installation of plumbing, and operation of the pump and accessories.

SPECIFICATIONS : Maximum specifications refer to individual attributes. It is not implied that all maximums can be performed simultaneously. If more than one maximum is considered, check with your CAT PUMPS supplier to confirm the proper performance and pump selection. Refer to individual pump Data Sheets for complete specifications, parts list and exploded view.

LUBRICATION : Fill crankcase with CAT PUMPS custom-blend, ISO-68 hydraulic oil per pump specifications [84 oz., 2.5 L]. DO NOT RUN PUMP WITHOUT OIL IN CRANKCASE. Change initial fill after 50 hours running period. Thereafter, change oil every 3 months or 500 hour intervals. Oil adjustment is vertical to start feed, horizontal to stop feed, dial to adjust flow rate. Additional lubrication may be required with increased hours of operation and temperature.

PUMP ROTATION : Pump was designed for forward rotation to allow optimum lubrication of the crosshead area. Reverse rotation is acceptable if the crankcase oil level is increased slightly above center dot to assure adequate lubrication.

PULLEY SELECTION: Select size of motor pulley required to deliver the desired flow from Horsepower Requirement and Pulley Selection Chart (refer to Tech Bulletin 003 or individual Data Sheet).

MOTOR SELECTION: The motor or engine driving the pump must be of adequate horsepower to maintain full RPM when the pump is under load. Select the electric motor from the Horsepower Requirement Chart according to required pump discharge flow, maximum pressure at the pump and drive losses of approximately 3-5%. Consult the manufacturer of gas or diesel engine for selection of the proper engine size.

MOUNTING: Mount the pump on a rigid, horizontal surface in a manner to permit drainage of crankcase oil. An uneven mounting surface will cause extensive damage to the pump base. To minimize piping stress, use appropriate flexible hose to inlet and discharge ports. Use the correct belt; make sure pulleys are aligned. Excessive belt tension may be harmful to the bearings. Hand rotate pump before starting to be certain shaft and bearings are free moving.

LOCATION : If the pump is used in extremely dirty or humid conditions, it is recommended pump be enclosed. Do not store or operate in excessively high temperature areas or without proper ventilation.

INLET CONDITIONS: Refer to complete Inlet Condition Check-List in this manual before starting system. DO NOT STARVE THE PUMP OR RUN DRY. Temperatures above 130°F are permissible. Add 1/2 PSI inlet pressure per each degree F over 130°F. Elastomer or RPM changes may be required. See Tech Bulletin 002 or call CAT PUMPS for recommendations.

C.A.T.: Installation of a C.A.T. (Captive Acceleration Tube) is recommended in applications with stressful inlet conditions such as high temperatures, booster pump feed, long inlet lines or quick closing valves.

DISCHARGE CONDITIONS: OPEN ALL VALVES BEFORE STARTING SYSTEM to avoid deadhead overpressure condition and severe damage to the pump or system.

Install a Pulsation Dampening device on the discharge head or in the discharge line as close to the head as possible. Be certain the pulsation dampener (Prrrrr-o-lator) is properly precharged for the system pressure (see individual Data Sheet).

A reliable Pressure Gauge should be installed near the discharge outlet of the high pressure manifold. This is extremely important for adjusting pressure regulating devices and also for proper sizing of the nozzle or restricting orifice. The pump is rated for a maximum pressure; this is the pressure which would be read at the discharge manifold of the pump, NOT AT THE GUN OR NOZZLE.

Use PTFE thread tape or pipe thread sealant (sparingly) to connect accessories or plumbing. Exercise caution not to wrap tape beyond the last thread to avoid tape from becoming lodged in the pump or accessories. This condition will cause a malfunction of the pump or system.

PRESSURE REGULATION: All systems require both a primary pressure regulating device (i.e., regulator, unloader) and a secondary pressure safety relief device (i.e., pop-off valve, safety valve). The primary pressure device must be installed on the discharge side of the pump. The function of the primary pressure regulating device is to protect the pump from over pressurization, which can be caused by a plugged or closed off discharge line. Over pressurization can severely damage the pump, other system components and can cause bodily harm. The secondary safety relief device must be installed in-line between the primary device and pump or on the opposite side of the manifold. This will ensure pressure relief of the system if the primary regulating device fails. Failure to install such a safety device will void the warranty on the pump.

If a large portion of the pumped liquid is by-passed (not used) when the high pressure system is running, this by-pass liquid should be routed to an adequately sized, baffled supply tank or to drain. If routed to the pump inlet, the by-pass liquid can quickly develop excessive heat and result in damage to the pump. A temperature control device to shut the system down within the pump limits or multiple THERMO VALVES must be installed in the by-pass line to protect the pump.

NOZZLES : A worn nozzle will result in loss of pressure. Do not adjust pressure regulating device to compensate. Replace nozzle and reset regulating device to system pressure.

PUMPED LIQUIDS : Some liquids may require a flush between operations or before storing. For pumping liquids other than water, contact your CAT PUMPS supplier.

STORING: For extended storing or between use in cold climates, drain all pumped liquids from pump and flush with antifreeze solution to prevent freezing and damage to the pump. DO NOT RUN PUMP WITH FROZEN LIQUID (refer to Tech Bulletin 083).

⚠ WARNING

All systems require both a primary pressure regulating device (i.e., regulator, unloader) and a secondary pressure safety relief device (i.e., pop-off valve, safety valve). Failure to install such relief devices could result in personal injury or damage to the pump or to system components. CAT PUMPS does not assume any liability or responsibility for the operation of a customer's high pressure system.



PIJTTERSEN

Pijtersen B.V.

Postbus 262, 8500 AG Joure

Transportwei 26, 8501 ZP Joure

The Netherlands

Tel.: +31 (0)513-414040


Fax: +31 (0)513-414066

E-mail : info@pijtersen.nl / info@catpumps.nl


Internet: www.pijtersen.nl / www.catpumps.nl




The Pumps with Nine Lives



Removal of Discharge Socket Head Screws



Separation of Discharge Manifold from Inlet Manifold



Discharge Manifold with both Inlet Valve Adapters and Discharge Valve Spacers.

CAUTION: Before commencing with service, shut off drive (electric motor, gas or diesel engine) and turn off water supply to pump. Relieve all discharge line pressure by triggering gun or opening valve in discharge line.

After servicing is completed, turn on water supply to pump, start drive, reset pressure regulating device and secondary valve, read system pressure on the gauge at the pump head. Check for any leaks, vibration or pressure fluctuations and resume operation.

SERVICING THE VALVES

Disassembly

1. To service the Valves, the Discharge Manifold must be removed. Using a M10 allen wrench remove the eight Socket Head Screws.
2. Support the underside of the Discharge Manifold and lightly tap the top back of the manifold with a soft mallet. Two screwdrivers may be needed to further separate the Discharge Manifold from the Inlet Manifold.
3. Remove the Discharge Manifold and place it **crankcase side up**.

NOTE: The Discharge Valve Assembly is secured in the upper chambers by the Discharge Valve Spacer, while the Inlet Valve Assembly is secured in the lower chambers by the Inlet Valve Adapter.

4. The Discharge Valve Spacers will remain in either the Inlet Manifold or the Discharge Manifold. To remove the Spacer from the manifold, insert two screwdrivers on opposite sides under the machined lip on the outside of the Spacer and pry out.

5. Use a reverse pliers to remove the Inlet Valve Adapters from the Discharge Manifold or insert two screwdrivers into the secondary groove on opposite sides of the adapter and pry from valve chamber.
6. Both the Inlet and Discharge use the same Valve Assembly. With a flat head screwdriver, carefully pry the Seat, O-Ring, Valve, Spring and Retainer from the manifold chamber.

CAUTION: Exercise caution to avoid scoring the manifold chamber wall.


NOTE: This Valve Assembly does not snap together.

Reassembly


NOTE: For certain applications apply liquid gasket to the O-Ring crevices and seal surfaces. See Tech Bulletin 053 for model identification.

NOTE: EPDM elastomers require a silicone-base lubricant.

1. Inspect the Spring Retainer for any scale buildup or wear and replace as needed. Place the Spring Retainer into the valve chamber.




Removal of Discharge Valve Spacers




Removal of Inlet Valve Adapters



Discharge Valve Assembly



Inlet Valve Assembly



Removal of I.M. Socket Head Screws



Rotate Crankshaft to position plungers

2. Examine the Spring for fatigue or breaks and replace as needed. Place the Spring into the Retainer.
3. Examine the Valve for pitting or grooves and replace as needed. Set the Valve onto the Spring with the **concave side down**.
4. Place the Seat into the valve chamber with the **concave side down**. Then apply liquid gasket to the O-Ring and press squarely into the lip on the Spring Retainer.

NOTE: Effective with 6-95 mfg date, the O-Ring was moved to the back side of the Seat with the O-Ring installed first, onto the lip in the manifold chamber, then the Seat with the machined O-Ring groove down.


NOTE: Effective with 11-95 mfg date, the Seat was modified to a new thicker style, still with the O-Ring installed first, onto the lip in the manifold chamber, then the Seat with the machined O-Ring groove down.

5. Examine the Seat for any grooves, pitting or wear and replace. Place the new Seat onto the the O-Ring with the concave side down.
6. Look for wear or damage to both the inner and outer O-Rings on the Inlet Adapter and replace.
7. Fit the O-Rings into both the outer groove and face groove of the Inlet Adapter and apply liquid gasket into the O-Ring crevice.


8. Press the Inlet Adapter into the lower manifold chamber.
9. Remove and examine both O-Rings on the Discharge Valve Spacer for wear or cuts and replace as needed.
10. Fit the new O-Rings into the groove on the outside of the Discharge Valve Spacer. Apply liquid gasket into the O-Ring crevice and carefully press the Spacer completely into the Discharge Manifold chamber with the **smaller diameter side down**.
11. Replace Discharge Manifold over the Plunger Rods with Discharge Valve Spacers to the top and Inlet Adapters to the bottom. Tap with a soft mallet until completely seated in chambers.
12. Reinstall the eight Socket Head Screws and torque in sequence to specifications in torque chart.

NOTE: It is highly recommended that antiseize lubricant (PN6119) be applied to the threads on all stainless steel components to prevent galling.


IMPORTANT: Follow the torque sequence to assure the proper alignment.




Removal of Inlet Manifold



Removal of Hi-Pressure Seals



Removal of Lo-Pressure Seals



Plunger Arrangement

SERVICING THE SEALS

Disassembly

1. Remove the Discharge Manifold as described in **SERVICING THE VALVES** section.
2. To service the seals the Inlet Manifold must be removed, use a M10 allen wrench to remove the 4 Socket Head Screws.
3. Support the Inlet Manifold and lightly tap the top back side with a soft mallet. Remove the Inlet Manifold and place it **crankcase side down**.
4. Use a reverse pliers to remove the Hi-Pressure Seals.
5. The Lo-Pressure Seals may stay on the Plungers or in the Inlet Manifold.
6. Invert the Inlet Manifold with the **crankcase side up**.
7. Remove the Lo-Pressure Seal using a reverse pliers or slide it off the Plunger by hand.

Reassembly

NOTE: If your pump has been built with special seals and O-Rings, service with same type of special parts. Refer to pump Data Sheet for correct parts or kits.

NOTE: For certain applications apply liquid gasket to the O-Ring crevices and seal surfaces. See Tech Bulletin 053 for model identification.

NOTE: EPDM elastomers require a silicone-base lubricant.

1. Examine the Lo-Pressure Seal for wear or spring fatigue and replace. Apply liquid gasket to the outside of the new Lo-Pressure Seal and carefully press it into the Inlet Manifold chamber with the **spring down**.

NOTE: When using alternate materials, the fit of the special materials may be snug and require gently driving the LPS into position with a cylinder of the same diameter to assure a square seating and no damage to the LPS.

2. Invert the Inlet Manifold and place the **crankcase side down**. Examine the Hi-Pressure Seal for deformity or wear and replace. Apply liquid gasket to the outside of the new Hi-Pressure Seal and carefully press it into the Inlet Manifold chamber with the **metal side down**.

SERVICING THE PLUNGERS

Disassembly

NOTE: The Ceramic Plungers and the Plunger Retainers should be examined on the same schedule as servicing the seals.

1. To service the Ceramic Plungers, first remove the Seal Retainers.
2. Loosen the Plunger Retainer about three or four turns using a M14 hex tool.
3. Grasp the Ceramic Plunger and push toward the Crankcase until it separates from the Plunger Retainer.
4. Unthread the Plunger Retainer with Gasket, O-Ring, Back-up-Ring and Ceramic Plunger. Remove the Keyhole Washer and Barrier Slinger from the Plunger Rod.

Reassembly

1. Examine the Barrier Slinger for any wear or damage and place on the Plunger Rod with the **concave side facing out**.
2. Examine the Keyhole Washer and place on the Plunger Rod with the **slot down**.
3. Examine the O-Ring and Back-up-Ring on the Plunger Retainer and replace if worn or damaged. First install the Gasket, then the O-Ring and Back-up-Ring. Lubricate the Plunger Retainer O-Ring to avoid cutting during installation.
4. If the Plunger Retainer unthreads from the stud during removal, thread the stud into the retainer.
5. Examine the Ceramic Plunger for scoring, cracks or scale and replace if needed. The Ceramic Plunger can be cleaned with a scotchbrite pad. Slide the Ceramic Plunger onto the retainer and stud assembly with the **shallower counterbore away from the retainer**.


NOTE: Plunger can only be installed one direction. Do not force into Plunger Rod.

NOTE: Do not lubricate wicks at initial start-up. Operate for 10 to 15 minutes to allow grease from LPS to penetrate the plunger surface, then lubricate as needed.

6. Apply Loctite® 242® to the threads of the Plunger Retainer Stud and thread onto the Plunger Rod. Then torque to specifications in chart.

7. Install new wicks in front half of seal retainer. Press rear half of seal retainer into front half until ends are flush. Holes should be to the top and bottom to line up with front retainer holes. Slide Seal Retainers over plungers and press into crankcase chamber until flush with oil seal.
8. Rotate the Crankshaft to line up the outside Plungers. Then lightly lubricate the Plungers with oil.
9. Carefully slide the Inlet Manifold over the Ceramic Plungers and press until flush with the Crankcase.
10. Reinstall the four Inlet Socket Head Screws and torque to specifications in chart.
11. The Hi-Pressure Seals may shift while installing the Inlet Manifold. Use one of the Discharge Valve Spacers to press the Seals back into position.
12. Carefully press the Discharge Manifold into the Inlet Manifold. Use a soft mallet to tap into place and reinstall the eight Socket Head Screws. Torque in sequence to specifications in torque chart.

TORQUE SEQUENCE



SERVICING THE CRANKCASE SECTION

1. While Inlet Manifold, Plungers and Seal Retainers are removed, examine Crankcase Oil Seals for leaking and wear.
2. Check for any signs of leaking at Rear Cover or Dipstick.
3. Check oil level and for evidence of water in oil. Change oil on a regular schedule. See Preventative Maintenance Check-List.
4. Rotate Crankshaft by hand to feel for smooth bearing movement.
5. Examine Crankshaft Oil Seals externally for drying, cracking or leaking.
6. Consult CAT PUMPS or your local distributor if Crankcase service is required. See also Tech Bulletin 035.

See Section II of the Plunger Pump Service DVD for additional information.

PREVENTATIVE MAINTENANCE CHECK-LIST						
Check	Daily	Weekly	50 hrs.	500 hrs.*	1500 hrs.**	3000 hrs.**
Clean Filters	x					
Oil Level/Quality	x					
Oil Leaks	x					
Water Leaks	x					
Belts, Pulley		x				
Plumbing		x				
Initial Oil Change			x			
Oil Change				x		
Seal Change					x	
Valve Change						x
Accessories					x	
* If other than CAT PUMPS custom-blend, multi-viscosity, ISO-68 hydraulic oil is used, change cycle should be every 300 hours. ** Each system's maintenance cycle will be exclusive. If system performance decreases, check immediately. If no wear at 1500 hours, check again at 2000 hours and each 500 hours until wear is observed. Valves typically require changing every other seal change. Duty cycle, temperature, quality of pumped liquid and inlet feed conditions all effect the life of pump wear parts and service cycle. ** Remember to service the regulator/unloader at each seal servicing and check all system accessories and connections before resuming operation. Refer to service DVD for additional assistance.						

TORQUE CHART						
Pump Item	Thread	Tool Size [Part No.]	Torque in. lbs. ft. lbs. Nm			
Plunger Retainer	M7	M14 Hex [25053]	108	9.0	12.2	
Inlet Manifold Screws	M12	M10 Allen [33047]	355	30.0	40	
Discharge Manifold Screws	M12	M10 Allen [33047]	355	30.0	40	
Rear Cover/ Bearing Cover Screws	M8	M13 Hex [25324]	115	9.58	13	
Connecting Rod Screws	M8	M13 Hex [25324]	216	18.0	24	
Bubble Oil Gauge	M28	Oil Gauge Tool [44050]	45	3.8	5	

TECHNICAL BULLETIN REFERENCE CHART		
No.	Subject	Models
002	Inlet Pressure VS Liquid Temperature	All Models
003	Power Unit Drive Packages	3PFR - 68PFR, 10FR - 60FR
024	Lubrication of Lo-Pressure Seals	All Models
035	Servicing Crankcase Section	7PFR - 60PFR
036	Cylinder and Plunger Reference Chart	All Models
043	LPS and HPS Servicing	All Plunger Models
053	Liquid Gasket	All Plunger NAB-S.S. Models
064	By-Pass Hose Sizing	All Unloaders/Regulators
074	Torque Chart	Piston and Plunger Pumps
076	Valve Seat and O-Ring	2530 and 2537
077	Oil Drain Kit	All Models (except 2SF/4SF)
081	Seal Case and Wick	2530 and 2537
083	Winterizing a Pump	All Models
085	M8 Keyway	25FR, 25PFR, 28PFR
095	Galling Preventative	Stainless Steel Pumps

INLET CONDITION CHECK-LIST

Review Before Start-Up

Inadequate inlet conditions can cause serious malfunctions in the best designed pump. Surprisingly, the simplest of things can cause the most severe problems or go unnoticed to the unfamiliar or untrained eye. REVIEW THIS CHECK-LIST BEFORE OPERATION OF ANY SYSTEM. Remember, no two systems are alike, so there can be no **ONE** best way to set-up a system. All factors must be carefully considered.

INLET SUPPLY should exceed the maximum flow being delivered by the pump to assure proper performance.

- ☐ Open inlet shut-off valve and turn on water supply to avoid starving pump. **DO NOT RUN PUMP DRY.**
- ☐ Temperatures above 130°F are permissible. Add 1/2 PSI inlet pressure per each degree F over 130°F. Elastomer or RPM changes may be required. See Tech Bulletin 002 or call CAT PUMPS for recommendations.
- ☐ Avoid closed loop systems especially with high temperature, ultra-high pressure or large volumes. Conditions vary with regulating/unloader valve.
- ☐ Low vapor pressure liquids, such as solvents, require a booster pump and C.A.T. to maintain adequate inlet supply (where compatible).
- ☐ Higher viscosity liquids require a positive head and a C.A.T. to assure adequate inlet supply.
- ☐ Higher temperature liquids tend to vaporize and require positive heads and C.A.T. to assure adequate inlet supply.
- ☐ When using an inlet supply reservoir, size it to provide adequate liquid to accommodate the maximum output of the pump, generally a minimum of 6-10 times the GPM (however, a combination of system factors can change this requirement); provide adequate baffling in the tank to eliminate air bubbles and turbulence; install diffusers on all return lines to the tank.

INLET LINE SIZE should be adequate to avoid starving the pump.

- ☐ Line size must be a minimum of one size larger than the pump inlet fitting. Avoid tees, 90 degree elbows or valves in the inlet line of the pump to reduce the risk of flow restriction and cavitation.
- ☐ The line **MUST** be a FLEXIBLE hose, NOT a rigid pipe, and reinforced on SUCTION systems to avoid collapsing.
- ☐ The simpler the inlet plumbing the less the potential for problems. Keep the length to a minimum, the number of elbows and joints to a minimum (ideally no elbows) and the inlet accessories to a minimum.
- ☐ Use pipe sealant to assure air-tight, positive sealing pipe joints.

INLET PRESSURE should fall within the specifications of the pump.

- ☐ Acceleration loss of liquids may be increased by high RPM, high temperatures, low vapor pressures or high viscosity and may require pressurized inlet and C.A.T. to maintain adequate inlet supply. **DO NOT USE C.A.T. WITH SUCTION INLET.**
- ☐ Optimum pump performance is obtained with +20 PSI (1.4 BAR) inlet pressure and a C.A.T. for certain applications. With adequate inlet plumbing, most pumps will perform with flooded suction. Maximum inlet pressure is 70 PSI (4.9 BAR).
- ☐ After prolonged storage, pump should be rotated by hand and purged of air to facilitate priming. Disconnect the discharge port and allow liquid to pass through pump and measure flow.

INLET ACCESSORIES are offered to protect against over pressurization, contamination or temperature and control flow.

- ☐ A shut-off valve is recommended to facilitate maintenance.
- ☐ Installation of a C.A.T. is essential in applications with stressful conditions such as high temperatures, booster pump feed or long inlet lines. **Do not use C.A.T. with negative inlet pressure.**
- ☐ A stand pipe can be used in some applications to help maintain a positive head at the pump inlet line.
- ☐ Inspect and clean inlet filters on a regular schedule to avoid flow restriction.
- ☐ A pressure transducer is necessary to accurately read inlet pressure. **Short term, intermittent cavitation will not register on a standard gauge.**
- ☐ All accessories should be sized to avoid restricting the inlet flow.
- ☐ All accessories should be compatible with the solution being pumped to prevent premature failure or malfunction.
- ☐ Optional inlet protection can be achieved by installing a pressure cut off switch between the inlet filter and the pump to shut off pump when there is no positive inlet pressure.

BY-PASS TO INLET Care should be exercised when deciding the method of by-pass from control valves.

- ☐ It is recommended the by-pass be directed to a baffled reservoir tank, with at least one baffle between the by-pass line and the inlet line to the pump.
- ☐ Although not recommended, by-pass liquid may be returned to the inlet line of the pump if the system is properly designed to protect your pump. When a pulsation dampener is used, a PRESSURE REDUCING VALVE must be installed on the inlet line (**BETWEEN** THE BY-PASS CONNECTION AND THE INLET TO THE PUMP) to avoid excessive pressure to the inlet of the pump. It is also recommended that a THERMO VALVE be used in the by-pass line to monitor the temperature build-up in the by-pass loop to avoid premature seal failure.
- ☐ A reinforced, flexible, low pressure hose rated up to 300 PSI should be used for routing by-pass back to the pump inlet.
- ☐ Caution should be exercised not to undersize the by-pass hose diameter and length. Refer to Technical Bulletin 064 for additional information on the size and length of the by-pass line.
- ☐ Check the pressure in the by-pass line to avoid over pressurizing the inlet.
- ☐ The by-pass line should be connected to the pump inlet line at a gentle angle of 45° or less and no closer than 10 times the pump inlet port diameter e.g. 1-1/2" port size = 15" distance from pump inlet port.

HOSE FRICTION LOSS

Water* Flow Gal/Min	PRESSURE DROP IN PSI PER 100 FT OF HOSE WITH TYPICAL WATER FLOW RATES Hose Inside Diameters, Inches						
	1/4	5/16	3/8	1/2	5/8	3/4	1"
0.5	16	5	2				
1	54	20	7	2			
2	180	60	25	6	2		
3	380	120	50	13	4	2	
4		220	90	24	7	3	
5		320	130	34	10	4	
6			220	52	16	7	1
8			300	80	25	10	2
10			450	120	38	14	3
15			900	250	80	30	7
20			1600	400	121	50	12
25				650	200	76	19
30					250	96	24
40					410	162	42
50					600	235	62
60						370	93

*At a fixed flow rate with a given size hose, the pressure drop across a given hose length will be directly proportional. A 50 ft. hose will exhibit one-half the pressure drop of a 100 ft. hose. Above values shown are valid at all pressure levels.

WATER LINE PRESSURE LOSS PRESSURE DROP IN PSI PER 100 FEET

Water GPM	Steel Pipe—Nominal Dia.						Brass Pipe—Nominal Dia.						Copper Tubing O.D. Type L							
	1/4	3/8	1/2	3/4	1	1 1/4	1 1/2	1/4	3/8	1/2	3/4	1	1 1/4	1 1/2	1/4	3/8	1/2	5/8	3/4	7/8
1	8.5	1.9						6.0	1.6						120	13	2.9	1.0		
2	30	7.0	2.1					20	5.6	1.8					400	45	10	3.4	1.3	
3	60	14	4.5	1.1				40	11	3.6					94	20	6.7	2.6		
5	150	36	12	2.8				100	28	9.0	2.2				230	50	17	6.1	3.0	
8	330	86	28	6.7	1.9			220	62	21	5.2	1.6			500	120	40	15	6.5	
10	520	130	43	10	3.0			320	90	30	7.8	2.4			180	56	22	10		
15	270	90	21	6.2	1.6			190	62	16	5.0	1.5			120	44	20			
25	670	240	56	16	4.2	2.0		470	150	40	12	3.8	1.7		330	110	50			
40					66	17	8.0					39	11	5.0				550	200	88
60						37	17						23	11						
80							52	29					40	19						
100						210	107	48					61	28						


RESISTANCE OF VALVES AND FITTINGS

Nominal Pipe Size Inches	Inside Diameter Inches	Equivalent Length of Standard Pipe in Feet							
		Gate Valve	Globe Valve	Angle Valve	45° Elbow	90° Elbow	180° Close Ret	Tee Thru Run	Tee Thru Branch
1/2	0.622	0.41	18.5	9.3	0.78	1.67	3.71	0.93	3.33
3/4	0.824	0.54	24.5	12.3	1.03	2.21	4.90	1.23	4.41
1	1.049	0.69	31.2	15.6	1.31	2.81	6.25	1.56	5.62
1¼	1.380	0.90	41.0	20.5	1.73	3.70	8.22	2.06	7.40
1½	1.610	1.05	48.0	24.0	2.15	4.31	9.59	2.40	8.63
2	2.067	1.35	61.5	30.8	2.59	5.55	12.30	3.08	11.60
2½	2.469	1.62	73.5	36.8	3.09	6.61	14.70	3.68	13.20
3	3.068	2.01	91.5	45.8	3.84	8.23	18.20	4.57	16.40
4	4.026	2.64	120.0	60.0	5.03	10.80	23.90	6.00	21.60

Arriving at a total line pressure loss, consideration should then be given to pressure loss created by valves, fittings and elevation of lines.

If a sufficient number of valves and fittings are incorporated in the system to materially affect the total line loss, add to the total line length, the equivalent length of line of each valve or fitting.

TYPICAL RESERVOIR TANK RECOMMENDED 6 TO 10 TIMES SYSTEM CAPACITY



Handy Formulas to Help You

Q. How can I find the RPM needed to get specific GPM (Gallons Per Minute) I want?

$$A. \text{Desired RPM} = \text{Desired GPM} \times \frac{\text{Rated RPM}}{\text{Rated GPM}}$$

Q. I have to run my pump at a certain RPM. How do I figure the GPM I'll get?

$$A. \text{Desired GPM} = \text{Desired RPM} \times \frac{\text{Rated GPM}}{\text{Rated RPM}}$$

Q. Is there a simple way to find the approximate horsepower I'll need to run the pump?

$$A. \text{Electric Brake Horsepower Required} = \frac{\text{GPM} \times \text{PSI}}{1460} \quad (\text{Standard 85\% Mech. Efficiency})$$



Q. What size motor pulley should I use?

$$A. \text{Pump Pulley (Outer Diameter)} \times \frac{\text{Pump RPM}}{\text{Motor/Engine RPM}} \quad (\text{Consult Engine Mfr.})$$

Q. How do I calculate the torque for my hydraulic drive system?

$$A. \text{Torque (ft. lbs.)} = 3.6 \left(\frac{\text{GPM} \times \text{PSI}}{\text{RPM}} \right)$$

Avoid Cavitation Damage



One or several of the conditions shown in the chart below may contribute to cavitation in a system resulting in premature wear, system downtime and unnecessary operating costs.

CONDITION	SOLUTION
Inadequate inlet line size	• Increase line size to the inlet port or one size larger
Water hammering liquid acceleration/deacceleration	• Install C.A.T. Tube • Move pump closer to liquid supply
Rigid Inlet Plumbing	• Use flexible wire reinforced hose to absorb pulsation and pressure spikes
Excessive Elbows in Inlet Plumbing	• Keep elbows to a minimum and less than 90°
Excessive Liquid Temperature	• Use Thermo Valve in bypass line • Do not exceed pump temperature specifications • Substitute closed loop with baffled holding tank • Adequately size tank for frequent or high volume bypass • Pressure feed high temperature liquids • Properly ventilate cabinets and rooms
Air Leaks in Plumbing	• Check all connections • Use PTFE thread tape or pipe thread sealant
Agitation in Supply Tank	• Size tank according to pump output — Minimum 6-10 times system GPM • Baffle tank to purge air from liquid and separate inlet from discharge
High Viscosity Liquids	• Verify viscosity against pump specifications before operation • Elevate liquid temperature enough to reduce viscosity • Lower RPM of pump • Pressure feed pump • Increase inlet line size
Clogged Filters	• Perform regular maintenance or use clean filters to monitor build up • Use adequate mesh size for liquid and pump specifications

DIAGNOSIS AND MAINTENANCE

One of the most important steps in a high pressure system is to establish a regular maintenance program. This will vary slightly with each system and is determined by various elements such as the duty cycle, the liquid being pumped, the actual specifications vs rated specifications of the pump, the ambient conditions, the inlet conditions and the accessories in the system. A careful review of the necessary inlet conditions and protection devices required before the system is installed will eliminate many potential problems.

CAT PUMPS are very easy pumps to service and require far less frequent service than most pumps. Typically, only common tools are required, making in-field service convenient, however, there are a few custom tools, special to certain models, that do simplify the process. This service manual is designed to assist you with the disassembly and reassembly of your pump. The following guide will assist in determining the cause and remedy to various operating conditions. You can also review our **FAQ** or **SERVICE** sections on our **WEB SITE** for more facts or contact CAT PUMPS directly.

PROBLEM	PROBABLE CAUSE	SOLUTION
Low pressure	•Worn nozzle. •Belt slippage. •Air leak in inlet plumbing. •Pressure gauge inoperative or not registering accurately. •Relief valve stuck, partially plugged or improperly adjusted. •Inlet suction strainer (filter) clogged or improperly sized. •Abrasives in pumped liquid. •Leaky discharge hose. •Inadequate liquid supply. •Severe cavitation. •Worn seals. •Worn or dirty inlet/discharge valves.	•Replace with properly sized nozzle. •Tighten belt(s) or install new belt(s). •Tighten fittings and hoses. Use PTFE liquid or tape. •Check with new gauge. Replace worn or damaged gauge. •Clean/adjust relief valve. Replace worn seats/valves and o-rings. •Clean filter. Use adequate size filter. Check more frequently. •Install proper filter. •Replace discharge hose with proper rating for system. •Pressurize inlet and install C.A.T. •Check inlet conditions. •Install new seal kit. Increase frequency of service. •Clean inlet/discharge valves or install new valve kit.
Pulsation	•Faulty Pulsation Dampener. •Foreign material trapped in inlet/discharge valves.	•Check precharge. If low, recharge, or install a new dampener. •Clean inlet/discharge valves or install new valve kit.
Water leak		
•Under the manifold	•Worn High Pressure or Lo-Pressure Seals. •Worn adapter o-rings.	•Install new seal kit. Increase frequency of service. •Install new o-rings.
•Into the crankcase	•Humid air condensing into water inside the crankcase. •Excessive wear to seals and V-Packings.	•Install oil cap protector. Change oil every 3 months or 500 hours. •Install new seal kit. Increase frequency of service.
Knocking noise		
•Inlet supply	•Inadequate inlet liquid supply.	•Check liquid supply. Increase line size, pressurize or install C.A.T.
•Bearing	•Broken or worn bearing.	•Replace bearing.
•Pulley	•Loose pulley on crankshaft	•Check key and tighten set screw.
Oil leak		
•Crankcase oil seals.	•Worn crankcase oil seals.	•Replace crankcase oil seals.
•Crankshaft oil seals and o-rings.	•Worn crankshaft oil seals or o-rings on bearing cover.	•Remove bearing cover and replace o-rings and/or oil seals.
•Drain plug	•Loose drain plug or worn drain plug o-ring.	•Tighten drain plug or replace o-ring.
•Bubble gauge	•Loose bubble gauge or worn bubble gauge gasket.	•Tighten bubble gauge or replace gasket.
•Rear cover	•Loose rear cover or worn rear cover o-ring.	•Tighten rear cover or replace o-ring.
•Filler cap	•Loose filler cap or excessive oil in crankcase.	•Tighten filler cap. Fill crankcase to specified capacity.
Pump runs extremely rough		
•Inlet conditions	•Restricted inlet or air entering the inlet plumbing	•Correct inlet size plumbing. Check for air tight seal.
•Pump valves	•Stuck inlet/discharge valves.	•Clean out foreign material or install new valve kit.
•Pump seals	•Leaking High Pressure or Lo-Pressure seals.	•Install new seal kit. Increase frequency of service.
Premature seal failure	•Scored plungers. •Over pressure to inlet manifold. •Abrasive material in the liquid being pumped. •Excessive pressure and/or temperature of pumped liquid. •Running pump dry. •Starving pump of adequate liquid. •Eroded manifold.	•Replace plungers. •Reduce inlet pressure per specifications. •Install proper filtration at pump inlet and clean regularly. •Check pressure and inlet liquid temperature. •DO NOT RUN PUMP WITHOUT LIQUID. •Increase hose one size larger than inlet port size. Pressurize and install C.A.T. •Replace manifold. Check liquid compatibility.