

# CRANKCASE OIL LEVEL INDICATOR



Model 76144 shown



Model 76334 shown

## Simplify Crankcase Oil Monitoring and Oil Changes

A pump maintenance program involves monitoring crankcase oil levels and routinely changing the crankcase oil as recommended. Routine pump maintenance prevents costly downtime, production interruption, emergency repairs, and costly pump replacement. Crankcase oil level kits make it easier to perform pump maintenance.

### Features and Benefits:

- Crankcase oil kits improve pump maintenance practices
- Convenient site indicator location so crankcase oil can be easily read or drained (models 76144 and 76334)
- Protected indicator shield can be rotated 360° for optimum viewing
- Vented oil indicator assures level is always accurate (models 76144 and 76334)
- Kits are equipped with oil drain plugs for fast and convenient oil change

# Which Model is Best for You?

All 25 and 60 frame pumps are equipped with dipsticks for oil level verification. The new crankcase oil level indicator (model 76144) allows easier crankcase oil verification and a convenient method to drain the oil for maintenance. Simply mount the indicator at the pump oil drain fitting and read the level at-a-glance. A drain plug is supplied with the indicator for scheduled oil change.



Model 76144

Our second option (model 76334) fits on all 3 to 60 frame piston and plunger pumps. This option includes the new crankcase oil level indicator model 76144 and our standard oil drain kits.

Some pumps within this frame range are equipped with a standard bubble oil gauge site mounted in the rear cover. In some instances the bubble gauge can be hidden based on its mounting configuration. For example, in a belt drive configuration the bubble gauge is obscured by the motor, making it difficult to read the oil level. This new oil indicator/drain kit provides the freedom to mount the indicator in a location where it can be easily read by maintenance personnel. The kit also makes scheduled oil changes very convenient.



Model 76334

## Crankcase Oil Level Indicator and Drain Kit

Model	Description	Models
76144	Crankcase oil level indicator with adapter and plug	Piston pumps: 1520 thru 6041 Plunger pumps: 2510 thru 6861K except 35 and 38 frame series
76334	Crankcase oil level indicator with oil drain kit 34334	All piston and plunger pumps and 66DX, except plunger pumps 1DX, 2DX, 2SF, 2SFX, 3DX, 3DNX, 3SP, 3SPX and 4SF series.

## Oil Drain Kits (without crankcase oil level indicator)

Model	Description	Models
34334	Oil drain kit with 3/8" x 24" drain hose, bracket, 1/4" NPTM square end oil drain plug and other fittings	All piston and plunger pumps and 66DX, except plunger pumps 1DX, 2DX, 2SF, 2SFX, 3DX, 3DNX, 3SP, 3SPX and 4SF series.
34314	Oil drain kit with 3/8" x 48" drain hose, bracket, 1/4" NPTM square end oil drain plug and other fittings	Piston pumps: 6020 thru 6041 Plunger pumps: 3501 thru 3560, 3801 thru 3841K, 6747 thru 6777, and 6801 thru 6861K
990394	Oil drain kit with 3/8" x 24" drain hose, bracket, 1/4" NPTM square end oil drain plug and other fittings	Plunger pumps: 1DX, 2DX, 2SF, 2SFX, 3DX, 3DNX, 3SP, 3SPX and 4SF series.

**The new pump crankcase oil level indicators are ideal for new systems or retrofitting existing systems. Let your customers know about this great new maintenance tool from Cat Pumps.**



## PIJTTERSEN

Pijtersen B.V.  
Postbus 262, 8500 AG Joure  
Transportwei 26, 8501 ZP Joure  
The Netherlands

Tel.: +31 (0)513-414040  
Fax: +31 (0)513-414066  
E-mail : [info@pijtersen.nl](mailto:info@pijtersen.nl) / [info@catpumps.nl](mailto:info@catpumps.nl)  
Internet: [www.pijtersen.nl](http://www.pijtersen.nl) / [www.catpumps.nl](http://www.catpumps.nl)

